

**QNix® 4500: The global bestseller for standard applications.
A handy and robust gauge for easy and fast coating thickness measurements – for all paint and automobile applications.**

QNix® 4500 was developed for a broad spectrum of use in the automobile and painting industries. This compact gauge allows for extremely accurate measurements of paint and corrosion protection thicknesses, both on steel and iron as well as on non-ferrous metals such as aluminum, zinc or copper.

Professionals immediately recognize the practice-oriented product properties as the handwriting of AUTOMATION Dr. Nix:

Extremely precise

High measuring accuracy over the entire measuring range.

Simple operation

No calibration. One button only.
One-hand operation.

Innovative technology

Proven Hall sensor and Eddy Current technology. Integrated measuring probe without cables or plugs.

Broad spectrum of use

Dual probe for measurements on steel and non-ferrous metals.

Protective measuring

Polished ruby tip to protect both the probe and the surface measured.



A quality product from



QNIX® 4500

Simply perfect

With the QNix® 4500, precise measurements on steel, iron and non-ferrous metals are simply perfect. Switch between the measuring procedures by simply pressing the button. No calibration required. High precision over the entire measuring range: Fe 3000 µm and NFe 3000 µm.

The sensitive QNix® 4500 measuring probe is fully integrated into this extremely small, light and handy gauge. Its readable LCD informs about readings, battery condition, mode of operation and serial number.

QNIX® 4200

For measurements on steel and iron, the identically designed QNix® 4200 is available.

Product advantages

- Gauge for standard applications – easy, safe and fast measurements.
- One-hand operation. Only one button.
- No calibration.
- Automatic On/Off switching.
- High precision over the entire measuring range: Fe 3000 µm and NFe 3000 µm.
- Broad spectrum of use for non-destructive measurements on steel, iron and non-ferrous metals such as aluminum, zinc, copper and brass.
- Compact design with integrated probe.
- Innovative, proven technology: Hall sensor and Eddy Current technology.
- Acoustic signal confirms taking of a measurement.
- Wear-proof ruby probe tip for long-term use.

Optimal LCD-Display

- Large clear numbers for optimum readability.
- Precise display of readings, battery condition, mode of operation and serial number.
- Readings displayed in µm or mil.

Scope of supply

- Coating thickness gauge QNix® 4500 (or QNix® 4200).
- Gauge carrying case with reference plates.
- 2 x 1,5 V Mignon Batteries (Type AA alkaline).
- Test certificate.
- Instruction manual.

Technical Data QNix® 4500 | 4200

Measuring Principle	Two magnetic measuring principles: Fe: Magnetic-Flux/Hall Effect ref Fe* NFe: Eddy Current (QNix® 4500 only)
Standards & Regulation	DIN EN ISO 2808, DIN 50981, ISO 2178, BS 5411 (3 & 11), BS 3900 - C5, ASTM B 499, ASTM D 1186, ASTM D 7091 (only QNix® 4500: DIN 50984, ISO 2360, ASTM D 1400)
Probe Type	integrated
Measuring Range	Fe: 0.0 – 3000 µm NFe: 0.0 – 3000 µm (QNix® 4500 only)
Metric System µm / mil	Yes
Measuring Interval	Single measurement: 850 ms
Display Metric	from 0.0 – 999 in µm, from 1000 µm in mm
Resolution	1 µm in the range up to 999 µm, 0.01 mm in the range from 1 mm
Accuracy according to Automation Dr. Nix Standards	± (2µm + 3% of the readings)
Minimum Measuring Area (in mm x mm)	10 x 10
Minimum Curvature	convex: 5mm, concave: 25mm
Minimum Substrate Thickness	Fe: 0.2 mm NFe: 0.05 mm (QNix® 4500 only)
Display	Graphic-LCD
Temperature Range	0 – 50° C
Permitted Storage Temperature	-10° C – 60° C
Power Supply	2 x Batteries: 1.5 V (Type AA Alkali)
Dimensions (L x W x H in mm)	100 x 60 x 27
Weight incl. Battery	appr. 105 g

Fe* Measuring of non-ferromagnetic coatings on ferromagnetic substrate, for example measuring on steel- or iron-substrates.

NFe* Measuring of non-ferromagnetic and electrically non-conductive coatings (insulating coatings) on non-ferromagnetic and electrically conductive substrate, for example measuring on aluminum-, zinc-, brass- and certain stainless (high-grade) steel-substrates.

Technical data subject to change without notice



* According to our terms of sale

AUTOMATION Dr. NIX
GmbH & Co. KG



001

Germany:

Robert-Perthel-Strasse 2 · 50739 Cologne

Phone +49 (0) 221-917455-0

Fax +49 (0) 221-171221

email info@qnix.de

www.qnix.de