



Perfection in Precision

SLIDER

OFFSET AND UV OFFSET

This compact system is ideal for accurate dispensing of concentrated inks for sheet-fed offset printing.

- The valves are individually activated by pneumatic cylinders, without rotating or mechanical parts, motors etc, making the system easy to operate
- The simple and economic Slider paste dispenser has up to 18 dispensing valves in two rows, and dispenses components into 1-20ltr cans (of a minimum 11cm diameter)
- There is no need for a washing system since the nozzle keeps the obturator surface clean by closing at the same level as the flat bottom of the valve
- The system is operated via a computer using Maestro® software
- Both piston and pressure plate pumps are available to carry base components to the dispensing head





Perfection in Precision

SLIDER

OFFSET AND UV OFFSET

ADVANTAGES

- Stock reduction and rationalization
- Improved color reproducibility
- Improved productivity
- Space and manpower savings
- Environmental protection
- Improved security and working conditions
- Waste reduction
- Improved flexibility
- Reduced machine downtime

TECHNICAL DATA

Components

18

Dispensing Accuracy

0.1 gr

Average Dispensing Time

2 min for a 2.5kg pail

Viscosity Range

30,000 - 500,000cps

Containers

2 - 25kg

